

ActivArmr® 43-216 (ex. ActivArmr® WorkGuard™)



Mechanical Protection



Special Purpose



Heavy



Durable and comfortable glove for welding applications

DESCRIPTION

- **ActivArmr® 43-216 is a heavy-duty special purpose glove offering high levels of molten splash resistance.** Ideal for many different applications requiring thermal protection, it also provides superior durability and good protection from cuts, punctures and abrasions.
- **Heat protection for a wide range of applications**
The ActivArmr®43-216 glove is certified as a Category III glove for protection against high temperatures and is rated with the EN 407 performance levels 413X4X. This makes the glove suitable for a large number of applications requiring heat resistance, including welding, operating machinery and working in environments with a risk of heat or molten splash.
- **Comfort**
With a soft inner jersey palm lining and a cotton denim cuff, ActivArmr® 43-216 is comfortable to wear.
- **Excellent durability and mechanical protection**
Made of tough-wearing leather, this heavy-duty glove is designed with palm reinforcement for added abrasion resistance.
Seams are made in Kevlar® and are reinforced by pieces of cowhide.
This construction provides superior mechanical protection.

PRODUCT DETAILS

Construction	Cut & sewn
Liner material	Cotton Jersey Kevlar® seams Leather (1.2 split cowhide A/B grade)
Cuff style	Gauntlet
Colour	Yellow
EN Sizes	9,10,11
Length (mm)	370-415
Packaging	6 pairs in a bag; 6 bags in a carton

IDEAL APPLICATIONS

- Loading & unloading with risk of heat or molten splash
- Welding

PRIMARY INDUSTRIES



STANDARDS AND CERTIFICATIONS

EN388:2003



3243

EN407



413X4X

EN388:2016



3243B

CATEGORY III

FEATURED TECHNOLOGY



Kevlar®

EXTRA FEATURES

Print date 21-05-2019

Ansell Healthcare Europe N.V. (European Head Office)

Riverside Business Park, Block J

Boulevard International 55, 1070 Brussels, Belgium

Tel. +32 (0) 2 528 74 00 • Fax +32 (0) 2 528 74 01 • Fax Customer Service +32 (0) 2 528 74 03

<http://www.ansell.eu> • E-mail info@ansell.eu

Ansell